EMS717U/EMS717P

Renewable Energy Sources

Ground Source Energy

Prof. Hua Sheng Wang

Content

- Origin, characteristics & potential of geothermal energy
- How to extract geothermal energy?
- Direct use: open groundwater systems
- Direct use: closed loop systems
- Design and implementation of heat pump system
- Design and implementation of ground heat exchanger
- Assessment of the system performance
- Economic analysis

Geothermal Energy

Geothermal resources can be divided into 3 distinct groups:-

- High temperature (HT)>150 °C for use in electrical power generation
- Intermediate temperature 30<(IT)<150 °C direct use for heating and hot water provision
- Low temperature (LT) <30°C, for cooling and for use with ground source heat pumps

Geothermal Energy

Most text books discuss these resources only


High temperature (HT)>150 °C for use in electrical power generation

Intermediate temperature 30<(IT)<150 °C direct use for heating and hot water provision


Much less on this

Low temperature (LT) <30°C, for cooling and for use with ground source heat pumps

Ground temperature vs Depth




Ground temperature vs Local depth



Ground source data in the UK

- Secret
- <10m
- •10<depth<30 m
- •>30m




Types of ground coupled cooling system

- Open loop normally direct use systems
- Closed loop
 - Direct use
 - Heat pump coupled

Open Loop Systems

Location of Open Loop GSHC Schemes in Central London




Groundwater cooling at Portcullis House







Groundwater cooling at Portcullis House




How groundwater occurs in rocks




The London Aquifer



Groundwater flow in London




Groundwater levels in London




Groundwater levels in London

Groundwater levels at Trafalgar Square, 1845-2001



http://www.bgs.ac.uk/research/groundwater/datainfo/levels/levels_data.html

Groundwater levels in London



•Interference with buildings foundations and underground infrastructure

To abstract water

- There needs to be water available!
- You may need a licence
- You may need to pay for the water you use
- You may need to pay to return the water to the sewers
- Is there an existing borehole?
- Speak to the Environment Agency

Abstraction charges

Schedule 3 Water Abstraction Charges for the year commencing 1 April 2016

The rates of charge for the year commencing 1st April 2016 are as follows:

Regional charging area	2016/17
	Standard
	Unit Charge
	(£/1000m3)
Anglian	27.51
Midlands	14.95
Northumbria	29.64
North West	12.57
Southern	19.23
South West (incl. Wessex)	19.71
Thames	13.84
Yorkshire	11.63
Dee	13.58
Wye	13.58

https://www.gov.uk/government/publications/abstraction-charges-scheme-april-2014-to-march-2015


Factors affecting viability

- Availability of resource: Depth of resource and ground material to be drilled.
- Confirm the resource quantity and well flow rate early
- Distance between resource and application site, most projects < 1500m
- Resource temperature (most approx. 12°C, London 14°C)
- Quality and composition of fluid
 - Particulates fouling and erosion
 - ·Bacteria fouling
 - Chemicals corrosion and fouling
- Disposal, Resource life

Before You Specify



Before You Specify



Closed loop systems

